



Prediction of DPA of irradiated samples based on the correlation with activation inventories

3rd DONES User Workshop | 1st Oct. 2024 | Zagreb

Yuefeng Qiu,

Irene Álvarez, Frederik Arbeiter, Santiago Becerril, Jesús Castellanos Axel Klix, Maria Luque




This work has been carried out within the framework of the EUROfusion Consortium and has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement number 633053. The views and opinions expressed herein do not necessarily reflect those of the European Commission.




- Introduction and Motivations
- Simulation methods
- Correlation studies
- Conclusions and discussions

Introduction and Motivations


- IFMIF-DONES: Accelerator-based neutron source (D+: 125 mA, 40 MeV), generating fusion-relevant neutrons through Li(d,xn) reactions
- DONES and material irradiation
 - Test cell (TC) houses the target assembly and the High Flux Test Module (HFTM)
 - **HFTM** container provide **4 x 8 sample slots**, with the center 4 x 4 slots material samples and other as reflectors
 - Small Specimen Testing Technique (**SSTT**) **samples** are located in specimen capsules surrounded by heaters for temperature control.
 - **Neutron flux of 1-5 10¹⁴ n/cm²/s, damage rate of 5-20 dpa/fpy**




Neutron flux (n/cm²/s)




DPA (dpa/fpy) distribution




IFMIF-DONES




Test cell



HFTM



SSTT specimens



HFTM container




- Introduction and Motivations
- **Simulation methods**
- Correlation studies
- Conclusions and discussion

Simulation methods

- Simulation codes and data
 - Neutronics model: Detailed HFTM and Li target
 - Simulation code: McDeLicious-MCNP(v6.2), **FISPACT-II.5** (API version)
 - Nuclear data: FENDL3-1d for neutron transport, **TENDL-2017 for neutron activation**, special displacement cross section [1] for EUROFER.
- Simulation setup
 - Calculation of the average flux in the **HFTM center regions**, average flux in the HFTM capsules.
 - Neutron flux spectra: CCFE 709 group.
 - Irradiation time : 345 days
 - Cooling time : from 1 hour to arbitrary long (1000 years).
- Studied regions and quantities
 - **HFTM region, Capsule 1-16, mesh (6x8x8)**
 - Activity, **gamma intensity (counts)**

DPA and activation calculation on the same mesh.

[1]A. Y. Konobeyev, et.al., "Evaluation of advanced displacement crosssections for the major EUROFER constituents based on an atomistic modelling approach," *Kerntechnik*, vol. 80, no. 1, pp. 7–12, Mar. 2015.






- Materials used for the simulations

- For HFTM capsule: a homogenous mixture of EUROFER 75% Na 25%;
- For activation: **1 cm³** of 100% **EUROFER** (density 7.87 g/cm³)

Homogenous (EUROFER 75% Na 25%)



Element	Min. wt% [10 ⁻² g/g]	Max. wt% [10 ⁻² g/g]	Target wt% [10 ⁻² g/g]	Recommended (*) [10 ⁻² g/g]
Alloying elements				
Fe	balance	balance	balance	balance
C	0.09	0.12	0.11	0.11
Mn	0.2	0.6	0.4	0.4
Cr	8.5	9.5	9.0	9.0
V	0.15	0.25	0.2	0.2
Ta	0.10	0.14	0.12	0.12
W	1.0	1.2	1.1	1.1
N	0.015	0.045	0.03	0.03

Element	Min. wt% [10 ⁻² g/g]	Max. wt% [10 ⁻² g/g]	Target wt% [10 ⁻² g/g]	Recommended (*) [10 ⁻² g/g]
Impurities				
Ti		0.02		0.02
P		0.005		0.005
Si		0.05		0.05
S		0.005		0.005
Ni	ALAP	0.01		0.01
Mo	ALAP	0.005		0.005
Cu	ALAP	0.01		0.01
Nb	ALAP	0.005		0.005
Al	ALAP	0.01		0.01
B	ALAP	0.002		0.002
Co	ALAP	0.01		0.01
As(**)	As+Sn+Sb+Zr(**)	0.05		0.05
Sn(**)				0.05
Sb(**)				0.05
Zr(**)				0.05
O		0.01		0.01



EUROFER compositions (2006)
[EFDA_D_2MM3A6 v1.2]

- Activation calculations
 - Capsule-3, 345 day irradiation.
- Dominant nuclei
 - Fe-55: x-ray emitter
 - T1/2 : 2.74 year, X-ray : 5-6 keV
 - Mn-56: short-lived gamma emitter
 - T1/2 : **2.58 hour**, γ -ray : 1810 keV(27%) and 2113 keV (14%)
 - Cr-51: strong gamma emitter
 - T1/2 :**27.7 d** , γ -ray : 320.1 keV(9.91%)
 - **Mn-54**: strong gamma emitter, important isotope
 - T1/2 :**312 day** , γ -ray : **834.8 keV(99.98%)**
- For the time of **200-2000 days**, the Mn-54 gammas dominant the total gammas by more than 99%.



Mn-54 is suitable for accumulate neutron flux, as well as decay gamma measurement.

Gamma		
#	E_{γ} [keV]	I_{γ} (abs) [%]
1	834.848 3	99.976 7

Mn-54 decay gamma




- The pathways contribute to Mn-54
 - Fe-54 (n,p): 57.05%
 - Mn-55(n,2n): 4.34%
 - Fe-56 (n,2np): 8.76%
 - Fe-56(n,nd) 2.06% (n,t) 2.00%
 - (n,other) 25.10%
- Threshold reactions sensitive to neutrons > 1 MeV.
- Production from Fe-56 will be the main uncertainty
 - Multiple pathways, low qualities of nuclear data.
 - Consider to use IRDFF-II $Fe-nat(n,X)Mn-54$ data.



95% of Mn-54 are produced from Fe.
Threshold reaction dominant at 1-20 MeV.




- Displacement cross section for Fe
 - Dominant in the high energy, consistent with Mn-54 production
 - Flux spectra different for >0.1 MeV : 25-50%. How this will impact on DPA and Mn-54 production.
- Two approach for study the correlations
 - Direct DPA to Activation correlations**
 - Mn-54 \rightarrow unfolding neutron spectra \rightarrow DPA cal.




Displacement cross section of Fe

Mn-54 production is in a similar trend with displacement (DPA) cross section.



Neutron spectra ($n/cm^2/s/MeV$) in capsules





Neutron spectrum difference in capsules compare to HFTM average spectrum

- Introduction and Motivations
- Simulation methods
- **Correlation studies**
- Conclusions and discussion

- What happened when plot DPA together with Mn-54 activity
 - Cooling time: **180 days** (6 month)
 - Highly correlated distribution, in linear scale
 - A correlation ratio can be obtained at the measurement point.
 - This correlation is also observed at the far-source cells.


Liner correlation between DPA and Mn-54 Activities!



DPA and Mn-54 activity correlations



- Overall correlation studies at beam level
 - One measurement point (ref. point) : max DPA and Mn-54 activity point
 - Using correlation factor at the ref. point as base, evaluating over entire HFTM.




$$\text{Correlation_ref} = \text{DPA_ref} / \text{Act_Mn-54_ref}$$


$$\text{Ratio} = \text{Correlation_i} / \text{Correlation_ref}$$

$$C^{\text{ref}} = \frac{D^{\text{ref}}}{A^{\text{ref}}}$$

$$R = \frac{C^{\vec{r}}}{C^{\text{ref}}}$$




DPA and Mn-54 activities





Correlation ratio compare to the ref. point



- Extreme locations
 - Still using correlation factor of the previous ref. point
 - Overall less than 10%! Adding more local ref. point (measurement point) can help to improve accuracy of correlation factor.



One neutron flux measurement can be used for predicting entire HFTM sample!




- Methodologies of predicting DPA using Mn-54 activity




Prediction procedure is simple!
Measurement is necessary for some typical locations.

- Benefit of new DPA measurement approach
 - One capsule with $8.0 \times 4.0 \times 1.46 \text{ cm} = 46.7 \text{ cm}^3$, we can **save 5.8 cm^3** high flux volume (12.4%)
 - DONES provide $16 \times 46.7 \text{ cm}^3 = 747 \text{ cm}^3$ high flux irradiation volume with a total cost of 700-800 MEURO : **$\sim 1 \text{ M EURO per cm}^3$ high flux volume**
 - Using the new DPA approach to reduce the SPND, which save $16 \times 5.8 \text{ cm}^3 = 92.8 \text{ cm}^3$



Saving of more than 90 M EURO!!

Another 50-60cm³ provide by using backplate as sample!



Potential Use of IFMIF-DONES Target Back-Plate for Material Specimens
J. Nucl. Eng. 2022, 3(4), 385-397; <https://doi.org/10.3390/jne3040025>

- Summary

- The Mn-54 gammas dominant the gamma activity for a long period, it emits a high single energy gamma, and have long half-live of 312 days.
- The gammas from the sample (mostly from Mn-54) has good correlation with DPA, due to both cross section are dominant above 1 MeV
- Using one measurement point of flux spectra, we can predict sample DPA with 10% uncertainty in the center rows, and <20% near the edges.
- This approach could reduce the neutron diagnostics, and save around 12% of irradiation volume.

- Outlook

- Further studies have to be continued on the uncertainties from material compositions, irradiation compaigns, gamma measurements, nuclear data, etc.
- Experimental validation should be conducted before final adoption of this measure, using existing neutron source, and STUMM.

Thank you!



IFMIF
DONES
GRANADA

**THE KEY
TO
THE FUTURE**

FAIRNESS



Transparency
Collaboration
Loyalty

OPENNESS



Open doors
Open hearts
Open minds
Open ears

COMMITMENT



Ownership
Critical thinking
Determination
Respect

DIVERSITY



Cooperation
Equal opportunities
Inclusion